







DU70/DU71/DU72 Series

Digital Projector Quick Start Guide

Guide de démarrage rapide du projecteur numérique
Digitaler Projektor Kurzanleitung
Guida rapida del proiettore digitale
Guía de inicio rápido del proyector digital
Guia de iniciação rápida ao Projetor Digital
Digital projektor snabbstartsguide
Краткое руководство по работе с цифровым проектором
Snelgids voor Digitale projector
Skrócona instrukcja obsługi projektora cyfrowego
Dijital Projektör Hızlı Başlangıç Kılavuzu
Průvodce rychlým používáním digitálního projektoru
คู่มือเริ่มต้นใช้งานดีจิทัลโปรเจคเตอร์อย่างย่อ
デジタルプロジェクタ クイックスタート ガイド
디지털 프로젝터 빠른 시작 안내서
數位投影機快速使用指南
数字投影机快速使用指南
دليل البدء السريع لجهاز عرض رقمي




www.vivitekc corp.com



Quick Start Card

Warranty Card

Safety Card






1



2




3



4



5



OR

