

## **User's Manual**

# Dashcam DrivePro™ 10

2020/05 Version 1.0



## **Table of Contents**

1.	System Requirements	2
2.	Package Contents	3
3.	Getting Started	4
3	3-1 Overview	
3	3-2 Inserting a microSD Memory Card	5
3	3-3 Mounting the DrivePro and Connecting to Power	5
3	3-4 Function Buttons	8
3	3-5 LED Indicator Chart	9
4.	Recording Videos	10
4	4-1 Normal Recording	10
4	4-2 Emergency Recording	10
5.	Using the DrivePro App	11
5	5-1 Downloading and Installing the App	11
5	5-2 Connecting to the DrivePro	11
5	5-3 Playing Videos on a Smart Device	13
5	5-4 App Settings	14
6.	DrivePro Toolbox Software	16
7.	Transferring Files to a Computer	17
8.	Safety Cautions	19
9.	Troubleshooting	20
10.	Specifications	21
11.	Recycling and Environmental Protection	22
12.	EU Compliance Statement	23
13.	·	
14.		
	GNU General Public License (GPL) Disclosure	
16		26

## 1. System Requirements

System requirements for connecting the DrivePro to a desktop or a laptop with a working USB port:

- Windows® 7
- Windows® 8
- Windows® 10
- macOS<sup>®</sup> X 10.14 or later

System requirements for using the DrivePro Toolbox:

- Windows® 7
- Windows® 8
- Windows® 10
- macOS® X 10.14 or later

System requirements for using the DrivePro app:

- Android 6.0 or later
- iOS 11.0 or later

## 2. Package Contents

The DrivePro 10 dashcam package includes the following items:


DrivePro 10 Dashcam



Adhesive Mount



Car Adapter



microSD Memory Card



Quick Start Guide



## 3. Getting Started


## 3-1 Overview



#### 3-2 Inserting a microSD Memory Card

You must insert a microSD memory card into the DrivePro before you can start recording. Please use a microSD memory card with 16GB, 32GB, 64GB, or 128GB capacity (Class 10 or above).

1. Insert a microSD memory card into the card slot of the DrivePro.



**Format your memory card.** Always format a new memory card in the DrivePro before using it for the first time. To format a memory card, go to **Settings** in the DrivePro app.

The microSD card bundled with the DrivePro 10 does not require frequent formatting. However, for the best recording performance, we still recommend that the memory card be formatted on a regular basis.

Notice: Formatting will erase all data on the memory card.

#### **WARNING:**




- 1. DrivePro 10 supports the FAT32 and exFAT file formats, but not NTFS.
- 2. Make sure the allocation Unit Size of the microSD card is 32 KB or larger; if not, the DrivePro may not work properly.
- 2. To remove, push to eject the memory card out of the slot.




**WARNING:** Do not remove the memory card during shutdown to avoid damages to the memory card and loss of recorded videos.

#### 3-3 Mounting the DrivePro and Connecting to Power


1. Insert the mounting bracket into the socket on the front top of the DrivePro, and slide sideways until you hear a click.




- 2. Thoroughly clean and dry the area of the windshield you wish to mount the DrivePro.
- **3.** Peel off the protective film from the adhesive mount, and firmly attach the DrivePro to the windshield or the rear-view mirror.




4. Turn the adjustment knob anticlockwise to loosen, and then adjust the DrivePro's position.



**5.** After the DrivePro is in the best position, turn the adjustment knob clockwise to make sure that the DrivePro is securely locked in place.



**6.** Connect the small end (Micro-B) of the car adapter to the USB connector of the DrivePro.



- 7. Plug the other end of the car adapter in your car's lighter socket.
- **8.** After the car engine is switched on, the DrivePro will automatically turn on and start recording. To fine tune camera angle and complete settings, download the DrivePro app on your mobile device.

## **3-4 Function Buttons**



Mode	Emergency Recording / Reset Button	
Emergency	Short press the red button to manually activate	
Recording	Emergency Recording.	
	Long press the red button for 10 seconds to reset	
Restore to Default	device settings to default and format the memory	
Nestore to Delauit	card.	
	Notice: Formatting will permanently erase all data.	



Mode	Reset Pinhole	
Restart Device	<ul> <li>Insert a paperclip in the battery reset pinhole. Hold for a few seconds. The device will power off and restart.</li> <li>Notice: Restarting the device will not clear any existing data, but your last recording may fail to be saved.</li> </ul>	

#### 3-5 LED Indicator Chart



#### Recording:

LED	Wi-Fi	Status	Definition
		Flashing	Recording with Wi-Fi
• blue	On	Flashing Quickly	Emergency Recording with Wi-Fi
2.00		Solid	Standby with Wi-Fi*
		Flashing	Recording without Wi-Fi
red	Off	Flashing Quickly	Emergency Recording without Wi-Fi
ieu		Solid	Standby without Wi-Fi*

Note: Wi-Fi connection is only available when the DrivePro is connected to power.

#### Formatting memory card:

LED	Status	Definition
• red	Flashing Very Quickly	Formatting microSD card

#### Connected to a computer:

LED	Status	Definition
• red	Solid	Connected to computer

<sup>\*</sup>The DrivePro will stop recording when a card error occurs or when you tap Data / Settings using the DrivePro app.

## 4. Recording Videos

#### 4-1 Normal Recording

After the car engine is switched on, the DrivePro will automatically turn on and start recording. By default, one video file is saved for every one minute of recording. To adjust the recording length, go to **Settings** in the DrivePro app. After the car engine is switched off, the DrivePro will automatically save the current recording and power off.

**Note:** Lighter sockets of some types of vehicles will still supply power after the car engine is turned off. If your car is of this type, please unplug your dashcam from the lighter socket to avoid unnecessary power consumption and unexpected issues.

#### 4-2 Emergency Recording

30% of the storage space will be saved for emergency video files. Video files recorded in emergency mode are protected from being overwritten.

**Manual Event Recording:** During video recording, press the emergency button on the side of the DrivePro to manually activate Emergency Recording. The LED indicator will start flashing (either red or blue) quickly.



**G-Sensor Event Recording:** During video recording, the DrivePro will automatically activate Emergency Recording when detecting a collision.

- If the G-Sensor sensitivity is set to "High", even minor shocks will activate Emergency Recording mode.
- If the G-Sensor sensitivity is set to "Low", only significant shocks will activate Emergency Recording mode.

G-Sensor sensitivity can be adjusted or disabled in **Settings** in the DrivePro app.

**Note:** The earliest emergency file saved will be overwritten by the latest emergency file recorded once the 30% storage space is full.

## 5. Using the DrivePro App

Developed specifically for iOS and Android devices, the free-to-download DrivePro app allows you to wirelessly live stream real-time video footages while recording, adjust DrivePro settings, and play videos directly from your mobile devices.





#### 5-1 Downloading and Installing the App

1. Download and install the "DrivePro" application from App Store or from Google Play.




2. The icon will be displayed on the home screen of your smart device.

#### 5-2 Connecting to the DrivePro

- **1.** Before connecting to the DrivePro's Wi-Fi, make sure the dashcam is connected to power via a car adapter. Then, launch the DrivePro app on your smart device.
- 2. In the app, select the DrivePro 10 (**DP10**) icon.




3. Select the Wi-Fi network with **DP10** in the SSID. Enter the default password **12345678**.



**4.** Once the connection is established, you can start using app features such as Browser and ((>)) Live View.

## 5-3 Playing Videos on a Smart Device



- 1. To browse saved clips, tap Browser.
- 2. You can play back videos recorded in normal or emergency mode.
- 3. Tap download a video, or to delete.


Note: The camera stops recording when you tap Browser or Settings in the app, the front LED turns solid blue. The camera will resume recording when you quit the app.

## ((>)) Live View

To stream on your mobile device live, tap ((>)) Live View.

#### 5-4 App Settings

In Settings, you can modify video and device configurations.



#### **VIDEO**

**Resolution:** Set the resolution/quality for video recording.

Available options: 1080P 60FPS (default) / 1080P 30FPS / 720P 60FPS / 720P 30FPS

(Note: Available options are displayed depending on your model.)

**Exposure Value:** Adjust exposure composition value to lighten or darken the preview screen.

Available options: +2.0 / +1.5 / +1.0 / +0.5 / 0.0 (default) / -0.5 / -1.0 / -1.5 / -2.0

Video Length: Set the recording length of each recorded video file.

Available options: 1 min (default) / 3 mins / 5 mins

Microphone: Turn on/off the microphone during video recording.

Light Frequency: Select the appropriate frequency to avoid flashing A/C light.

Available options: 50Hz / 60Hz

#### **VIDEO STAMP**



Video Stamp: Display the time of the video being recorded.



Date / Time: Set the date and time format. You can select 24-hour or 12-hour time format.

Available options: YYYY/MM/DD / MM/DD/YYYY / DD/MM/YYYY, 24HR / AM/PM

#### **DEVICE**



G-Sensor: Adjust the sensitivity of the G-Sensor.

Available options: Disable / Low (default) / Medium / High



Delay Power Off: Schedule the DrivePro to shut down at a certain time.


Available options: Disable / 10 secs (default) / 30 secs



Wi-Fi: You may change the default SSID for the DrivePro's wireless network.

Note: If you change the SSID, it will be renewed when you reconnect to Wi-Fi.

#### **SYSTEM**





Format SD Card: Tap to format your microSD card.



Version: Tap to upgrade the firmware to the latest version.

WARNING: NEVER remove the power cable or the microSD memory card while the firmware is being upgraded.



- 1. The DrivePro<sup>™</sup> will shut down and the red LED light will flash while the firmware is being upgraded. After the upgrade is complete, the DrivePro<sup>™</sup> will restart automatically.
- 2. If the DrivePro<sup>™</sup> cannot be turned on due to firmware upgrade failure, please contact Transcend customer service for technical support.

## 6. DrivePro Toolbox Software

The DrivePro Toolbox features a user-friendly interface that allows you to select and play videos recorded on your DrivePro and display driving paths of recorded videos without the need to install extra codecs.

- 1. Download the software from: www.transcend-info.com/downloads
- 2. Install DrivePro Toolbox software on your desktop or laptop.

#### **Software Features**

- Video Sorting
   Easily sort videos by filename, recording date, or group.
- Smooth Video Playback
   Connect the DrivePro or use a microSD card supported card reader or adapter to play back
   recorded video events on your computer.
- Edit and Trim Videos
   Select a video, trim it and save it as a new clip immediately. You can also capture snapshots from your videos during playback.
- 4. Show Your Driving Paths
  View the driving paths of your journey displayed on maps along with the recorded video. This feature only works with DrivePro models with a GPS receiver.


## 7. Transferring Files to a Computer

To transfer files between the DrivePro's memory card and your computer:

**Option 1:** Take the microSD memory card out of the DrivePro, and insert to a compatible card reader to transfer files to your computer.

#### Option 2:

- 1. Insert the microSD memory card into the DrivePro.
- 2. Plug the small end of a USB (Micro-B) cable into the USB port located on the right-hand side of the DrivePro.
- **3.** Plug the large end of the cable into an available USB port on your desktop or laptop.





DrivePro package does not contain any USB cable.

#### Windows® 7 / 8 / 8.1 / 10

No drivers are required for connecting the DrivePro to your desktop or laptop. Windows® Operating Systems have built-in drivers to support your DrivePro. Upon successful connection to your computer, a new **Removable Disk** drive with a newly assigned drive letter representing the DrivePro will automatically appear in **My Computer**, and a Removable Hardware icon will appear in the Windows System Tray.





\*Note: (E:) is an example drive letter – the letter in your "My Computer" window may differ.

Your DrivePro is now ready to transfer data just like an external hard drive. To transfer videos, simply drag-and-drop files from the folder that represents the DrivePro.

#### Proper removal of your DrivePro from Windows:

- 1. Click once on the **Removable Hardware** icon in the system tray.
- 2. A Safely Remove Hardware window will pop up. Click to continue.
- **3.** Unplug your DrivePro from the USB port.



#### ■ macOS<sup>®</sup> X 10.14 or later

No drivers are required. Plug your DrivePro into an available USB port directly, and your computer will automatically detect it.



#### Proper removal of your DrivePro from Mac OS:

Drag-and-drop the Disk icon corresponding to your DrivePro into the trashcan, and then unplug your DrivePro from the USB port.

#### WARNING:

1. To prevent data loss, always follow the proper removal procedures when disconnecting the DrivePro from your computer.



- 2. When the DrivePro is connected to a computer, it can only be used for transferring files. You will not be able to use any of the DrivePro's features at this time. Please disconnect your DrivePro from the computer to resume normal function.
- 3. **NEVER** use the "format" or "initialize disk" function while the DrivePro is connected to your computer, even if prompted to do so.

## 8. Safety Cautions

These usage and safety guidelines are **IMPORTANT!** Please follow them carefully to ensure your own personal safety, and help protect your DrivePro from potential damages.

#### General Use

- For in-car use only.
- For your safety, do not operate the DrivePro, or use the DrivePro App while driving.
- Avoid placing the DrivePro in an extreme temperature environment.
- Avoid splashing water or any other liquids on the DrivePro and accessories.
- Do not use the DrivePro in an environment with strong magnetic fields or excessive vibration.
- Only use the car adapter provided by Transcend. Other car adapters may not compatible with the DrivePro.
- Lighter sockets of some types of vehicles will still supply power after the car engine is turned
  off. If your car is of this type, please unplug your car video recorder from the lighter socket to
  avoid unnecessary power consumption and unexpected issues.
- The GPS system is subject to changes which could affect its accuracy and performance.
   Transcend does not guarantee the accuracy of GPS data, which should not influence your personal judgment while driving.
- GPS signals cannot penetrate buildings and metallic tinted films. The accuracy of GPS data depends on the surroundings including the weather and the location it is being used (e.g. high buildings, tunnels, undergrounds and forests).
- Wi-Fi function is only available when the DrivePro is connected to power.

#### Mounting Location

- Never place the DrivePro where the driver's view or deployment of airbags is obstructed.
- Mount the DrivePro within the range of the windshield wipers to ensure clear visibility in rain.



**WARNING:** Remove the DrivePro carefully if it is mounted on a tinted window to prevent damages to the tinted film.

#### Backing up Data

- Transcend does NOT take any responsibility for data loss or damage during operation. We strongly advise that you regularly back up data in your memory card to a computer or other storage medium.
- To ensure Hi-Speed USB 2.0 data transfer rates when connecting your DrivePro to a computer, please check if the computer is installed correct USB drivers. If you are not sure how to check this, please refer to the User's Manual of the computer or motherboard for USB driver information.

## 9. Troubleshooting

If a problem occurs to your DrivePro, please first check the instructions listed on our website before sending your DrivePro for repair. If you cannot find any ideal solution to your question, please consult your dealer, service center, or local Transcend branch office for further help.

You can also visit Transcend website (https://www.transcend-info.com/Support/No-1145) for FAQs and technical support. For any Hardware issues, please refer to the DrivePro User's Manual.

## 10. **Specifications**

Connect Interface:	USB 2.0
Storage Capacity:	microSD, 16GB / 32GB / 64GB /128GB (Class 10 or above)
Dimensions:	58.3 mm (L) x 36 mm (W)x 22.8 mm (H) 2.3" (L) x 1.42" (W) x 0.9" (H)
Weight:	40g 1.41 oz
Battery	Li-Polymer
Power Supply for Hardwire Power Cable	Input DC 10V~28V / 1.35A Output DC 4.6V~5.25V / 2A
Power Supply for Car Lighter Adapter	Input DC 10V~28V / 1.5A Output DC 4.6V~5.25V / 2A
Power Supply for DrivePro	Input DC 5V / 2A
Operating Temperature:	-20°C (-4°F) ~ 60°C (140°F)
Video Format:	H.264 (MP4: up to 1920x1080P 60fps)
Lens:	F/2.0, 140° wide angle
Resolution / Frame Rate	Full HD 1920 x 1080P (60fps) (Default) Full HD 1920 x 1080P (30fps) HD 1280 x 720P (60fps) HD 1280 x 720P (30fps)
Wi-Fi	802.11b/g/n
Certification:	CE, FCC, BSMI, NCC
Warranty:	2-Year Limited

## 11. Recycling and Environmental Protection



**Recycling the Product (WEEE):** Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. When you see the crossed-out wheel bin symbol attached to a product, it means that the product is covered by the European Directive 2002/96/EC:

Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potential negative consequences on the environment and human health.



**Battery Disposal:** Your product contains a built-in rechargeable battery covered by the European Directive 2006/66/EC, which cannot be disposed of with normal household waste. Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health.

For products with non-exchangeable built in batteries: The removal of (or the attempt to remove) the battery invalidates the warranty. This procedure is only to be performed at the end of the product's life.

#### **CAUTION**

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

## 12. <u>EU Compliance Statement</u>

Transcend Information hereby declares that all CE marked Transcend products incorporating radio equipment functionality are in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: www.transcend-info.com/eu\_compliance



#### **Dashcam / Body Camera series**

Frequency:	Maximum transmit power:
2400-2483.5MHz	< 100mW
DrivePro Body 60	
Frequency:	Maximum transmit power:
2400-2483.5MHz	< 100mW
Frequency:	Maximum transmit power:
5150-5250MHz	< 100mW

## 13. Federal Communications Commission (FCC) Statement

This device complies with Part 15 FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received including interference that may cause undesired operation.

This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **RF Exposure Statement:**

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled

environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

#### **FCC RF Radiation Exposure Statement:**

This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## 14. Two-year Limited Warranty

This product is covered by a Two-year Limited Warranty. Should your product fail under normal use within two years from the original purchase date, Transcend will provide warranty service pursuant to the terms of the Transcend Warranty Policy. Proof of the original purchase date is required for warranty service. Transcend will inspect the product and in its sole discretion repair or replace it with a refurbished product or functional equivalent. Under special circumstances, Transcend may refund or credit the current value of the product at the time the warranty claim is made. The decision made by Transcend shall be final and binding upon you. Transcend may refuse to provide inspection, repair or replacement service for products that are out of warranty, and will charge fees if these services are provided for out-of-warranty products.

#### Limitations

Any software or digital content included with this product in disc, downloadable, or preloaded form, is not covered under this Warranty. This Warranty does not apply to any Transcend product failure caused by any accident, abuse, mishandling or improper usage (including use contrary to the product description or instructions, outside the scope of the product's intended use, or for tooling or testing purposes), alteration, abnormal mechanical or environmental condition (including prolonged exposure to humidity), acts of nature, improper installation (including connection to incompatible equipment), or problems with electrical power (including undervoltage, overvoltage, or power supply instability). In addition, damage or alteration of warranty, quality or authenticity stickers, and/or product serial or electronic numbers, unauthorized repair or modification, or any physical damage to the product or evidence of opening or tampering with the product casing will also void this Warranty. This Warranty shall not apply to the transferees of Transcend products and/or anyone who stands to profit from this Warranty without Transcend's prior written authorization. This Warranty only applies to the product itself, and excludes rechargeable batteries and all product accessories (such as cables and power adapters).

#### **Transcend Warranty Policy**

Please visit **www.transcend-info.com/warranty** to view the Transcend Warranty Policy. By using the product, you agree that you accept the terms of the Transcend Warranty Policy, which may be amended from time to time.



## Transcend Information, Inc.

www.transcend-info.com

\*The Transcend logo is a registered trademark of Transcend Information, Inc.

\*The specifications mentioned above are subject to change without notice.

\*All logos and marks are trademarks of their respective companies.

## 15. GNU General Public License (GPL) Disclosure

Firmware incorporated into this product and/or software used for this product may include third party copyrighted software licensed under the GPL (hereinafter referred to as "GPL Software"). In accordance with the GPL, if applicable: 1) the source code for the GPL Software may be downloaded at no charge or obtained on CD for a nominal charge by calling Customer Support within three years of the date of purchase; 2) you may copy, re-distribute and/or modify the GPL Software under the terms of the GNU General Public License as below or any later version, which may be obtained at http://www.gnu.org/licenses/gpl.html; 3) the GPL Software is distributed WITHOUT ANY WARRANTY, without even implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. The entire risk as to the quality and performance of the GPL Software is with you. Transcend does not provide any support for the GPL software.

## 16. End-User License Agreement (EULA)

#### Software license terms and conditions

- 1. **Generally.** Transcend Information, Inc. ("Transcend") is willing to grant the following license to install or use the software and/or firmware ("Licensed Software") pursuant to this End-User License Agreement ("Agreement"), whether provided separately or associated with a Transcend product ("Product"), to the original purchaser of the Product upon or with which the Licensed Software was installed or associated as of the time of purchase ("Customer") only if Customer accepts all of the terms and conditions of this Agreement. PLEASE READ THESE TERMS CAREFULLY. USING THE SOFTWARE WILL CONSTITUTE CUSTOMER'S ACCEPTANCE OF THE TERMS AND CONDITIONS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THE TERMS AND CONDITIONS OF THIS AGREEMENT, DO NOT INSTALL OR USE THE LICENSED SOFTWARE.
- 2. **License Grant.** Transcend grants to Customer a personal, non-exclusive, non-transferable, non-distributable, non-assignable, non-sublicensable license to install and use the Licensed Software on the Product in accordance with the terms and conditions of this Agreement.
- 3. **Intellectual Property Rights.** As between Transcend and Customer, the copyright and all other intellectual property rights in the Licensed Software are the property of Transcend or its supplier(s) or licensor(s). Any rights not expressly granted in this License are reserved to Transcend.
- 4. **License Limitations.** Customer may not, and may not authorize or permit any third party to: (a) use the Licensed Software for any purpose other than in connection with the Product or in a manner inconsistent with the design or documentations of the Licensed Software; (b) license, distribute, lease, rent, lend, transfer, assign or otherwise dispose of the Licensed Software or use the Licensed Software in any commercial hosted or service bureau environment; (c) reverse engineer, decompile, disassemble or attempt to discover the source code for or any trade secrets related to the Licensed Software, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation; (d) adapt, modify, alter, translate or create any derivative works of the Licensed Software; (e) remove, alter or obscure any copyright notice or other proprietary rights notice on the Licensed Software or Product; or (f) circumvent or attempt to circumvent any methods employed by Transcend to control access to the components, features or functions of the Product or Licensed Software.

- 5. **Copying.** Customer may not copy the Licensed Software except that one copy of any separate software component of the Licensed Software may be made to the extent that such copying is necessary for Customer's own backup purposes.
- 6. **Open Source.** The Licensed Software may contain open source components licensed to Transcend pursuant to the license terms specified as below,
  - (a) GNU General Public License (GPL), the terms of which is currently available at http://www.gnu.org/licenses/qpl.html;
  - (b) GNU Lesser General Public License (LGPL), the terms of which is currently available at http://www.gnu.org/copyleft/lesser.html; and/or
  - (c) Code Project Open License (CPOL), the terms of which is currently available at http://www.codeproject.com/info/cpol10.aspx

The above license terms will control solely with respect to the open source components. In the event that this Agreement conflicts with the requirements of the above one or more terms with respect to the use of the corresponding open source components, Customer agrees to be bound by such one or more license terms.

7. **Disclaimer.** TRANSCEND MAKES NO WARRANTY AND REPRESENTATIONS ABOUT THE SUITABILITY, RELIABILITY, AVAILABILITY, TIMELINESS, LACK OF VIRUSES OR OTHER HARMFUL COMPONENTS AND ACCURACY OF THE INFORMATION, LICENSED SOFTWARE, PRODUCTS, SERVICES AND RELATED GRAPHICS CONTAINED WITHIN THE LICENSED SOFTWARE FOR ANY PURPOSE. ALL SUCH INFORMATION, LICENSED SOFTWARE, PRODUCTS, SERVICES AND RELATED GRAPHICS ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND. TRANSCEND HEREBY DISCLAIMS ALL WARRANTIES AND CONDITIONS WITH REGARD TO THIS INFORMATION, LICENSED SOFTWARE, PRODUCTS, SERVICES AND RELATED GRAPHICS, INCLUDING ALL IMPLIED WARRANTIES AND CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, WORKMANLIKE EFFORT, TITLE, AND NON-INFRINGEMENT.

IN NO EVENT SHALL TRANSCEND BE LIABLE FOR ANY DIRECT, INDIRECT, PUNITIVE, INCIDENTAL, SPECIAL, CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF USE, DATA OR PROFITS, ARISING OUT OF OR IN ANY WAY CONNECTION WITH THE USE, PERFORMANCE OR ACCURACY OF THE LICENSED SOFTWARE OR WITH THE DELAY OR INABILITY TO USE THE LICENSED SOFTWARE, OR THE PRODUCT WITH WHICH THE LICENSED SOFTWARE IS ASSOCIATED, WHETHER BASED ON CONTRACT, TORT, NEGLIGENCE, STRICT LIABILITY OR OTHERWISE, EVEN IF TRANSCEND HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

- 8. Limitation of Liability. IN ANY CASE, TRANSCEND 'S LIABILITY ARISING OUT OF OR IN CONNECTION WITH THIS AGREEMENT WILL BE LIMITED TO THE TOTAL AMOUNT ACTUALLY AND ORIGINALLY PAID AT RETAIL BY CUSTOMER FOR THE PRODUCT. The foregoing Disclaimer and Limitation of Liability will apply to the maximum extent permitted by applicable law. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the exclusions and limitations set forth above may not apply.
- 9. **Termination.** Transcend may, in addition to any other remedies available to Transcend, terminate this Agreement immediately if Customer breaches any of its obligations under this Agreement.

10. **Miscellaneous.** (a) This Agreement constitutes the entire agreement between Transcend and Customer concerning the subject matter hereof, and it may only be modified by a written amendment signed by an authorized executive of Transcend. (b) Except to the extent applicable law, if any, provides otherwise, this Agreement will be governed by the law of the Republic of China, excluding its conflict of law provisions. (c) If any part of this Agreement is held invalid or unenforceable, and the remaining portions will remain in full force and effect. (d) A waiver by either party of any term or condition of this Agreement or any breach thereof, in any one instance, will not waive such term or condition or any subsequent breach thereof. (e) Transcend may assign its rights under this Agreement without condition. (f) This Agreement will be binding upon and will inure to the benefit of the parties, their successors and permitted assigns.