




Schrank Ulas 5-Fach Montageanleitung Instruction manual




VCM Morgenthaler GmbH
D-79346 Endingen am Kaiserstuhl
service@vcm-gruppe.de
www.vcm-gruppe.de

A




x2

B



x3

C



x3

D




x2

E




x2

e




f



x4


g

x4



M4x30

h




M4x18

x16


i

x4




j

x4



a

x12



b

x12




k

x2




l

x4




c

x12




d

x12




01




a	x12	b	x12	c	x12
					

02





d	x12
	

03




04




e	
	

05




f	x4	g	x4
			
		M4x30	

06




07



h	x16	i	x4	j	x4
					
M4x18					

08



k	x2	l	x4
			

