


Epson Ultra Glossy Photo Paper - Glänzend - 100

x 150 mm 50 Blatt Fotopapier - für EcoTank ET-1810 - 2810 - 2811 - 2814 - 2815 - 2820 - 2825 - 2826 - 2850 - 2851 - 2856 - 4800 - 4850

Gruppe	Papier, Folien, Etiketten
Hersteller	Epson
Hersteller Art. Nr.	C13S041943
EAN/UPC	0010343855540



Beschreibung

Mit diesem Ultra Glossy Photo Paper machen Sie den Profis von zu Hause aus Konkurrenz. Erstellen Sie mit diesem hochwertigen Fotopapier langlebige Fotos in Galeriequalität.

Hauptmerkmale

Produktbeschreibung	Epson Ultra Glossy Photo Paper - Fotopapier - glänzend - 50 Blatt - 100 x 150 mm
Produkttyp	Fotopapier
Ausführung der Oberfläche	Glänzend
Mediengröße	100 x 150 mm
Drucktechnologie	Tintenstrahl
Enthaltene Menge	50 Blatt
Kompatibel mit	EcoTank ET-1810, 2710, 2711, 2712, 2714, 2715, 2720, 2721, 2726, 2750, 2751, 2756, 2810, 2811, 2812, 2814, 2815, 2820, 2821, 2825, 2826, 2850, 2851, 2856, 3750, 4700, 4750, 4800, 4850, 7700, 7750; Expression Home XP-235; Expression Home HD XP-15000; Expression Premium XP-540, 6000, 6005, 900

Ausführliche Details

	Media
Medientyp	Fotopapier
Ausführung der Oberfläche	Glänzend
Mediengrößen	100 x 150 mm
Drucktechnologie	Tintenstrahl
Enthaltene Menge	50 Blatt
	Informationen zur Kompatibilität
Kompatibel mit	Epson Artisan 730 Epson EcoTank ET-1810, ET-2710, ET-2710 Unlimited, ET-2711, ET-2712, ET-2714, ET-2715, ET-2720, ET-2720 All-in-One Supertank Printer, ET-2720 Unlimited, ET-2721, ET-2721 Unlimited, ET-2726, ET-2750, ET-2750U, ET-2751, ET-2756, ET-2810, ET-2811, ET-2812, ET-2814, ET-2815, ET-2820, ET-2821, ET-2825, ET-2826, ET-2850, ET-2850U, ET-2851, ET-2856, ET-3750, ET-4700, ET-4700 Unlimited, ET-4750, ET-4750 Unlimited, ET-4750U, ET-4800, ET-4850, ET-4850U, ET-7700, ET-7750

Epson Expression Home XP-202, XP-205, XP-212, XP-215, XP-225, XP-235, XP-235A, XP-245, XP-247, XP-320, XP-33, XP-342, XP-345, XP-400, XP-400 Small-in-One, XP-405, XP-415, XP-420, XP-422, XP-424, XP-432, XP-435, XP-442, XP-445, XP-530
Epson Expression Home HD XP-15000
Epson Expression Photo XP-55, XP-750, XP-760, XP-850, XP-860, XP-950, XP-960
Epson Expression Premium XP-530, XP-540, XP-540 Media Bundle, XP-6000, XP-6005, XP-605, XP-610, XP-615, XP-620, XP-630, XP-635, XP-640, XP-645, XP-810, XP-900, XP-900 Stickers
Epson Stylus Pro 3880, Pro 3880 Mirage Edition, SX115, SX130, SX210, SX215, SX235W, SX415, SX435W, SX445W, SX515W, SX535WD, SX610FW
Epson Stylus Office B1100, B42WD, BX305F, BX310FN, BX320FW, BX610FW, BX635FWD, BX925FWD
Epson Stylus Photo PX650, PX660, PX710W, PX730WD, PX810FW, PX830FWD
Epson SureColor P800 Designer Edition, SC-P800
Epson WorkForce 7510, WF-100, WF-2010W, WF-2520, WF-2520NF, WF-2530, WF-2530WF, WF-2540, WF-2540WF, WF-2630, WF-2630WF, WF-2650DWF, WF-2660, WF-2660DWF, WF-2750DWF, WF-2760DWF, WF-3620DWF, WF-3620DWF Stickers, WF-3640, WF-3640DTWF, WF-7110DTW, WF-7515, WF-7610, WF-7610DWF, WF-7620, WF-7620DTWF
Epson WorkForce Pro WF-4630, WF-4630DWF, WF-4640, WF-4640DTWF, WF-5190, WF-5190DW, WF-5690, WF-5690DWF, WF-6090DW, WF-6590DWF, WF-R5190 DTW Flex, WF-R5190 DTW Flex BAM, WF-R5690 DTWF Flex BAM, WF-R5690DTWF Flex, WF-R8590 D3TWFC Flex, WF-R8590 DTWFC Flex, WF-R8590DTWF Flex, WP-4530, WP-4540

Technische Daten © 1WorldSync. Technische Änderungen und Irrtümer vorbehalten.