

# Product Safety Information

## EXPO 600 tipping container

Please note the technical data of the products!

**Article Numbers:** 73715, 73714, 73713, 73712, 73711, 73710

### Safety Instructions:

- Ensure that the tipping container is always used on a stable surface.
- Do not exceed the maximum load capacity of 1000 kg and observe the high load capacity.
- Empty the tipping container before tipping and put it down safely after use to prevent tipping.
- Warning of risk of injury due to improper use; take appropriate protective measures.
- Caution when using forklift trucks: Position and use the entry pockets correctly.
- Handling should only be carried out by qualified personnel and protective clothing should be used.
- Attach safety labelling in accordance with the legal requirements.
- Inspect for mechanical damage and wear before use and at regular intervals; do not neglect maintenance.
- Read the instructions for use carefully and follow them to ensure safe handling.
- Ensure protection against unauthorised access to the tipping container in industrial environments.
- Ensure that the load centre of gravity is correctly adjusted to prevent tipping.
- Use only for the intended commercial purpose; not suitable for private use.
- No persons or animals in the danger zone during the tipping process; do not use in extreme weather conditions.
- Observe protective measures to avoid crushing and cutting injuries.
- Ensure that the tilt mechanism is regularly checked for functionality.
- There is a risk of tipping if used incorrectly.
- Do not tip near edges or precipices.
- Do not use in extreme weather conditions that could jeopardise the integrity of the material.