Product Safety Information

Folding floor container FB 2000 with rubber suspension

Please note the technical data of the products!

Article Numbers: 76071, 76066, 76065, 76064, 76063, 76062

Safety Instructions:

- Observe safety precautions to avoid injuries due to improper use.
- The bottom flap could slam shut suddenly when emptying, so be careful when operating it. Operate the cable pull in a controlled manner.
- Maximum load capacity: 1500 kg. There is a risk of damage or injury if overloaded.
- The product is heavy (weight up to 255 kg), use suitable aids for transport. Attention: Weight of approx. 232 kg (painted) or 255 kg (galvanised).
- Powerful device, supervision required if used by untrained persons.
- Wear protective clothing (gloves, protective footwear) to avoid injury.
- Ensure that nobody is standing underneath the bottom flap when it is being emptied.
- The product is not suitable for children as it does not fulfil any child safety standards. Avoid the risk of suffocation from unattended children in the vicinity.
- Only use the product for its intended purpose.
- Before use, ensure that all safety devices are functional.
- When using with pallet trucks, ensure sufficient load capacity. Use only recommended with an underride height of 100 mm.
- When using cranes, ensure that the loads are properly secured. Use equipment suitable for the weight.
- When setting up for the first time, ensure that the container is in a safe and stable position. Ensure that the hinged floor container is standing on a stable surface.
- Ensure that the product is properly maintained to avoid defects.
- Do not place hands or feet in the area of moving parts to avoid injury.
- Check the functionality of transport equipment (e.g. pallet truck, crane) before use.
- Only trained persons may move or operate the hinged floor container.
- Please ensure that the drop sides and the bottom flap are securely locked before transporting the container.
- Only use forks that are compatible with the container.
- Safety precautions against unintentional slipping or tipping must be observed.
- Check the condition and operating conditions of the container before use.
- Ensure use in safe areas without obstacles during transport.