

Product Safety Information

Scissor roll webs, web width 600 mm

Manufacturer/Responsible Person: Blume-Rollen GmbH, Röntgenstr. 1-3, 42477 Radevormwald, Deutschland

E-Mail: info@blume-rollen.de

Please note the technical data of the products!

Article Numbers: 154819, 154818, 154817, 154816

Safety Instructions:

- Make sure that the load capacity of 120 kg is not exceeded to ensure safe use.
- The scissor roller conveyors should be used on a stable and level surface and stability should be monitored, especially when the conveyor length is extended, to prevent tipping.
- When using in curves and S-curves, the operating instructions should be observed to avoid accidents.
- Wear protective gloves to avoid injury from sharp edges or moving parts.
- The castors should only be used on suitable surfaces and ensure that they are properly secured to prevent them from rolling away.
- Check the stability of the supports with variable height (700 - 1100 mm) regularly to ensure safe operation.
- Ensure that the distance between the axles (32 - 130 mm) meets the safety requirements.
- Provide and follow instructions for the safe installation and use of the flexible routing.
- The use of steel or plastic rollers with ball bearings should be checked from a safety point of view.
- Clearly communicate safety instructions for moving parts; there is a risk of injury from moving parts.
- Provide warnings regarding choking hazard due to small parts.
- Stability check required: If used improperly, the track can tip over or collapse.
- Do not use for commercial use without appropriate safety precautions.
- Observe the maximum load capacity: Overloading can lead to damage and hazards.
- Avoid using the tracks when they are not in a fixed position to prevent them from tipping over or slipping.
- The scissor roller conveyors should only be operated by trained personnel in order to avoid injuries.