

Product Safety Information

Circular saw blade AD 254mm Z.80 WZ Bohr.30mm Schnitt-B.2,6mm HM BOSCH

Manufacturer/Responsible Person: Robert Bosch Power Tools GmbH, Max-Lang-Str. 40-46, 70771 Leinfelden-Echterdingen, Deutschland
E-Mail: kontakt@bosch.de

Please note the technical data of the products!

Article Numbers: 733766, 733765

Safety Instructions:

- Always use suitable protective equipment such as safety goggles and hearing protection when working with the circular saw.
- Always keep your hands and other body parts away from the saw blade during operation.
- Ensure that the saw blade is properly installed and sharp to minimise injury.
- Store the saw blade in a dry place and out of the reach of children.
- If in doubt, consult the manual or a specialist for the correct use and maintenance of the circular saw.
- Risk of cuts and stabs from the blade.
- Observe the safety information and instructions for use.