

# Product Safety Information

## Circular saw blade AD 190mm Z.54 HLTCG Bohr.30mm Schnitt-B.1,8mm HM BOSCH

**Manufacturer/Responsible Person:** Robert Bosch Power Tools GmbH, Max-Lang-Str. 40-46, 70771 Leinfelden-Echterdingen, Deutschland  
**E-Mail:** kontakt@bosch.de

Please note the technical data of the products!

**Article Numbers:** 734709, 734708

### Safety Instructions:

- Wear protective gloves and safety goggles when using the circular saw blade.
- Ensure that the saw blade is mounted securely and correctly.
- Cutting is dangerous for unprotected persons; keep all persons at a safe distance.
- Use only on suitable machines intended for this type of accessory.
- Check for damage and cracks before use.
- Use in accordance with the speed specifications of the machine.
- Use only by trained personnel.
- Caution: Saw blade may have sharp edges.
- Do not store near children. Choking hazard due to small parts.
- Read and observe the operating instructions before use.
- Use only for the intended purpose. Improper use can lead to injuries.
- Store safely after use to avoid injury.