

Product Safety Information

EURO sump tray 250/2 CEMO, polyethylene, with approval, various versions Versions

Manufacturer/Responsible Person: CEMO GmbH, In den Backenländern 5, 71384 Weinstadt, Deutschland

E-Mail: kontakt@cemo-group.com

Please note the technical data of the products!

Article Numbers: 139257, 139256, 139255

Safety Instructions:

- Use the drip tray only for the storage of water-polluting substances of GHS 1-4.
- Before use, ensure that the drip tray is undamaged.
- Suitable protective gloves must be worn when storing corrosive chemicals and protective equipment must generally be used.
- Do not overload the collection tray; observe the maximum collection volume of 224 litres.
- Dispose of in accordance with the applicable regulations for hazardous waste and clean thoroughly after use.
- Check the drip tray regularly for cracks or damage.
- Use the grating to avoid direct contact with hazardous substances.
- Only use for recommended chemicals such as AdBlue®, alkalis, acids and other aggressive chemicals.
- In the event of spillage of hazardous liquids, take immediate measures to contain the danger.